

Pre-recorded Sound Tone and Sound Combination Chart


The combination of sounds(General)

17 pre-recorded sound tones for standard type products

Sound Number	Sound Tone	Sound Number	Sound Tone
SND01	Fire.A-ANG	SND10	Cuckoo's Waltz
SND02	Emergency WA-U(Yelp)	SND11	Piano Sonata
SND03	Ambulance PI-PO(Hi-low)	SND12	Turkish March
SND04	Abandon Alarm	SND13	Beep Intermittent
SND05	Machinery Fault	SND14	Door Chime
SND06	High Expansion	SND15	Phone Ring
SND07	7 Short Pl./1 Long	SND16	PI.PI.PI Short
SND08	Sweet Home	SND17	Tripping Beat
SND09	For Elise		

Standard sound combination for WS/WP/WM/WA type products

ON = 1/OFF = 0


ON OFF 

17 sounds per combination can be selected according to your preference. 4 combinations are available.

No.	1	2	3	Ch1	Ch2	Ch3	Ch4	Ch5
0	0	0	0	No sound				
1	0	0	1	SND01 Fire.A-ANG	SND02 Emergency WA-U	SND03 Ambulance PI-PO	SND05 Machinery Fault	SND06 High Expansion
2	0	1	0	SND01 Fire.A-ANG	SND04 Abandon Alarm	SND05 Machinery Fault	SND06 High Expansion	SND07 7 Short Pl./1 Long
3	0	1	1	SND08 Sweet Home	SND09 For Elise	SND05 Machinery Fault	SND11 Piano Sonata	SND12 Turkish March
4	1	0	0	SND13 Beep Intermittent	SND14 Door Chime	SND15 Phone Ring	SND16 PI.PI.PI Short	SND17 Tripping Beat

※ You can select sound tones using the 3P switches located on the circuit board of the WS/WP/WM/WA Type products.

Sound tone combinations for standard type products




- 5 types of sounds (5 warning sounds (WS), 5 special warning sounds (WP), 5 melodies (WM), 5 alarms (WA), and 5 voice signals (WV) can be selected and played individually.
- The signal wire lead-out type product replaces the channel selection switch with external wiring.

Sound Category	Channel	Sound Tone	Sound Combination #
WS 5 warning sounds	Ch1	Fire.A-ANG	WS/WP/WM/WA No.1
	Ch2	Emergency WA-U(Yelp)	
	Ch3	Ambulance PI-PO(Hi-low)	
	Ch4	Machinery Fault	
	Ch5	High Expansion	
WP 5 special warning sounds	Ch1	Fire.A-ANG	WS/WP/WM/WA No.2
	Ch2	Abandon Alarm	
	Ch3	Machinery Fault	
	Ch4	High Expansion	
	Ch5	7 Short Pl./1 Long	
WM 5 melodies	Ch1	Sweet Home	WS/WP/WM/WA No.3
	Ch2	For Elise	
	Ch3	Cuckoo's Waltz	
	Ch4	Piano Sonata	
	Ch5	Turkish March	
WA 5 alarms	Ch1	Beep Intermittent	WS/WP/WM/WA No.4
	Ch2	Door Chime	
	Ch3	Phone Ring	
	Ch4	PI.PI.PI Short	
	Ch5	Tripping Beat	
WV 5 customizable sound	Ch1	1. Voice messages are pre-recorded and provided from factory upon user's request 2. Each channel has recording space for 16 sec 3. 5 channels available 4. When only one channel is used, maximum recordable space is 80 sec	-
	Ch2		
	Ch3		
	Ch4		
	Ch5		

※ Please refer to [Pre-recorded Sound Tone and Sound Combination Chart] for detailed information about selectable sound patterns.

※ In case of customized WV 5 tone type, there may be difference of volume depending on user's audio file type.

Sound Selection of Signal Sounds



- Standard specification : Use internal switches Turn on dip switches of each channel, designated sound will be played.